

HelixDrive Vacuum Pump Operating Manual



NAVAC Inc.

www.navacvacuum.com
Tel/Fax: +1 877 MY-NAVAC
877 696 2822

Failure to

Failure to follow warnings could result in death or serious injury.

SAVE THIS MANUAL FOR FUTURE REFERENCE



Contents

1. Use Information	
2. Attention	
3. Product Overview ·····	
3.1 Working Principle Diagram of HD Series Vacuum Pump	4
3.2 Schematic Diagram of Purge Piping of HD Series Vacuum Pump	5
4. Check before Installation	7
4.1 Specifications & Model ·····	
4.2 Accessories and Appearance	
4.3 Precautions for Handling ·····	
4.4 Precautions for Hoisting	
5. Technical Parameters & Specifications	8
6. Installation Process	
6.1 Installation	
6.2 Installation Specifications	
6.3 Pumping Rate Curve	
7. Handling and Storage	
8. Check & Maintenance	
8.1 Daily maintenance list	
8.2 Routine maintenance methods	
9. Troubleshooting	
9.1 Check Methods for Rotor Rotation	
9.2 Error Code Query of Controller	
9.3 Examples for Faults	
10. Warranty	
11. Accessories	
12. Annex	
12.1 HD8/20/40 MODBUS-RTU Communication Protocol	
12.2 Relationship Between Purge Gas Flow and Purge Pressure of HD8/20/40	
12.3 HD20/40 Full communication control operation method	34

Empowering you to work smarter



Use Information

Thanks for choosing NAVAC vacuum pump of high reliability (Hereinafter referred to as "the pump"). Please check carefully whether the product received is the same as you ordered and the accessories, spare parts & operating manual are attached as well. Please also check if there's any damage occurred during transportation. If needed, contact the local distributor or our sales team.

In order to maintain a stable performance level of the pump, read this operating manual carefully to fully understand the safety instructions, technical data as well as operating procedures before installation, operation, repair and maintenance of the pump.



Marning

Failure to observe the terms could result in serious personal injury.



Failure to observe the terms could result in damage to the pump.



This warning label indicates risk of electrical shock. Disconnect the pump from the power supply before beginning with connections, repair and maintenance. Make sure the cover of junction box is properly installed before running.



This warning label indicates high temperature hazard. Do not touch the pump when the pump is in operation.

⚠ Notice

Read the operating manual carefully and follow the operating procedures. We reserve the right to modify the design and technical data of the pump without notice which may have discrepancies in the manual. Add vacuum oil as requested before starting the new pump.

Attention

In order to ensure the personal safety, read the operating manual carefully before installation, operation, repair and maintenance.



Warning

- 1). Make sure the power supply used is the one marked on the product. Connect power supply by personnel holding an electrician license according to the technical standards of power equipment and
- 2). Cut off the power supply before checking or repairing the pump, so as to avoid personal injury or death due to electric shock or sudden start of the pump.
- 3). Before starting the pump, make sure that the power supply of motor is the one marked on the product. The rated current of the selected cable and motor protection switch must match the rated current on
- 4). The product cannot be used for pumping active, corrosive, toxic, flammable or explosive gases. If necessary, please feel free to contact us.



Warning

- 5). Please do not place any object that affects ventilation effect around the motor, so as to avoid scalding or fire caused by abnormal temperature rise.
- 6). Make sure the exhaust port is kept unblocked prior to running the pump. It is forbidden to block or restrict air flow of the exhaust port in any way. The size of the exhaust pipe shall be such designed to ensure that the absolute pressure does not exceed 1.15 bar (relative pressure does not exceed

▲ Notice

- 1). If the vacuum degree and current become abnormal, check whether the exhaust port is blocked. If the exhaust filter element is installed, check whether the element needs cleaning or replacing.
- 2). The ambient temperature of the pump is 5-40°C.
- 3). Check the oil level of the gear box before running the pump. Do not use the pump without oil or oil shortage in the gear box, otherwise the pump will fail.
- 4). Please fill oil to the pump in strict accordance with the requirements of scale line. Excessive oil may cause pump failure. The normal oil level is at 1/3 of the oil immersion lens.




Fig. 1

- 5). When the pump runs abnormally or the total running time exceeds 6,000 hours, remove the front plate
- a. If the lubricating oil turns dark or the oil level is lower than min. requirements, replace or add oil instead.
- b. Tighten the filler plug and drain plug after oil change or filling; otherwise the vacuum degree will be affected and oil leakage may occur.
- c. Fill the specified vacuum pump oil.

2

Empowering you to work smarter



- 6). Connect the pump to the vacuum system by placing pump feet directly on the ground horizontally or connecting pump feet via bolts.
- 7). The temperature of pump surface may be very high when the pump is running and within 1 hour after it stops running. Therefore, it is forbidden to touch the surface of gear box and the pump in order to avoid
- 8). Please install the pump stably and firmly within an angle of 10° . Otherwise, the gear lubricating oil will flow into the pump cavity, which may cause vibration, noise and even damage of the pump.
- 9). Please dispose waste oils and other parts according to relevant environmental protection regulations
- 10). Use corresponding accessories when pumping a small amount of dust; otherwise, pump failure or sharp performance drop will occur.
- 11). Non-professionals are forbidden to disassemble the pump. Otherwise, pump may be damaged or fail to run normally. Where necessary, please feel free to contact us.




Product Overview

This product is a dry screw vacuum pump, which belongs to a kind of basic vacuum obtaining equipment. In particular, it is applicable to plasma cleaning, freeze drying, analytical instruments, laboratories, etc., and can also be used as a backing pump for Roots pumps.

The pump exhausts the gas in the pumped container by constant suction – compression – exhausting via two rotors which rotate to the opposite directions, in order to form vacuum. There is a certain gap between screws and between screws and the pump body, which do not contact with each other. No lubricating oil exists in the pump cavity; The spiral groove formed by the pump body and the mutually meshed screw separates the whole pump cavity into spaces of different sizes. Gas is compressed and transmitted in the spaces from large to small ones. The pump has the advantages of stable operation, low noise, high ultimate vacuum and low power consumption.


3.1 Working Principle Diagram of HD Series Vacuum Pump



Empowering you to work smarter



3.2 Schematic Diagram of Purge Piping of HD Series Vacuum Pump



(a) Purge inlet



Fig.4




3.2.1 Preparations before purging





Remove the dust plug amounted on the quick connector

Connect one end of the hose with an outer diameter of Ø 6 with the air source and the other with the quick connector. Remarks: The air source must be dry nitrogen or dry compressed air





- . The barometer should be 0.5~1MPa when the air supply is connected.
- Is connected.

 2. The pressure may also be manually adjusted by user by turning the relief valve knob at the lower part. To inquire the relationship between pressure and flow, please refer to Annex 12.3 Relationship between Purge Flow and Purge Pressure of HD20/40 Series




3.2.2 Process of purge gas entering pump body

Purge gas passes through 1 quick connector, 2 high-pressure gas pipe B, 3 ferrule taper thread adapter L6.35-R1/4, 4 relief valve, 5 ferrule taper thread adapter L6.35-R1/4, 6 high-pressure gas pipe C, 7 relief valve, 8 high-pressure gas pipe A and 9 ferrule taper thread adapter L6.35-R1/8.

3.2.3 Gas ballast assembly

In the absence of nitrogen access conditions, the pumped medium contains condensable gases, it is necessary to open the gas ballast!

Open the gas ballast will be able to control the gas flow (usually dry air at room temperature) through the gas ballast holes into the screw pump in the pump cavity gas in the compression process with the pumping vapor mixing. When the gas mixture is compressed to exhaust pressure, the vapor partial pressure can be maintained in the pump temperature state below the saturation vapor pressure, so the vapor will not condense.



Empowering you to work smarter



Check before Installation

4.1 Specifications & Model .

Please check whether the specification of the vacuum pump meet your needs.

4.2 Accessories and Appearance

Upon receiving the vacuum pump, please check whether the attached parts are complete. For any doubt, please feel free to contact us. Accessories for all HD series 20/40 dry screw vacuum pumps:

Items	Qty.	Unit
DB15 wiring leaflet	1	Piece
User Manual	1	Pcs
Hex wrench (3mm-type 7)	1	Set
Hex wrench (4mm-type 7)	1	Set
Hex wrench (5mm-type 7)	1	Set
Hex wrench (8mm-type 7)	1	Set
Power cord 1	1	Set
DB15male head (short pins 7 and 8)	1	Set
DB15male head with cables and with cable number	1	Set

Table 1

4.3 Precautions for Handling

The HD8/20/40 is equipped with a pair of directional wheels and 2 legs. Lift one end of the legs when trying to move the machine.

4.4 Precautions for Hoisting

A silencer is designed at the bottom of the vacuum pump. It is forbidden to lift the vacuum pump without protection. Instead, sling is recommended for handling.



Technical Parameters & Specifications

Specification of Power Cord							
Confirm the voltage of power supply voltage							
Voltage	Voltage 90-120V 200-220V 380-415V						
Models	Wire di	iameter Wire diameter			Wire diameter		
HD8	1.5mm²	14AWG	1.5mm²	14AWG			
HD20	1.5mm²	14AWG 1.5mm² 14AWG					
HD40	1.5mm²	14AWG	1.5mm²	14AWG			

Table 2

Technical Parameters

	Model	Unit	HD8	HD20	HD40		
		m³/h	8	20	32		
Pe	ak pumping speed	L/min	130	330	530		
		cfm	4.7	11.7	18.8		
		Pa		1			
Ultim	nate vacuum	Torr		7.5×10 ⁻³			
		mbar		1×10 ⁻²			
	Dry nitrogen/ Dry compressed air	slm		0~50			
Gas purge	Pressure	Mpa	1 ′ [0.05~0.1			
F 3 -	Purge gas Inlet connection			One-touch fitting Φ6mm			
	Purge gas supply quality		ISO8673 CLASS 2				
Voltage In	put	V	200-240V 1-phase				
Voltage fre	equency	Hz	50/60				
Motor ratir	ng	kW		1.8			
Ultimate p	ower consumption	kW	1.1				
Maxmium power consumption		kW		3			
Current at	ultimate pressure	А	6	7	8		
Heavy dut	y peak current	А	13	13	13		

Empowering you to work smarter



	Model	Unit	HD8	HD20	HD40	
	PID function		PID functions			
	Analog input		Analogue speed control			
Control	Enabling mode		Parallel control and	monitoring: Digital and	d modbus-rtu control	
	Communication function		Serial co	mmunication: MODE	BUS-RTU	
Inlet/exhaust	DN		KF25/KF16	KF25	KF25	
Water vapor	treatment capacity	g/h	135	200	200	
Gas ballast		•	1	Opti	onal	
Lifting ring			M10 lifting ring (optional)			
Operating hu	umidity		Below 90%			
Maintenance	cycle		1 time/year			
Cooling mod	le		Forced-air			
Operating te	mperature range (storage)	°F	41~104 (23~122)			
Lubrication v	volume (Oil type)			80 (PEFP)		
Noise		dB(A)	≤58	≤60		
Dimensions(L*W*H)	in	20.5x11.8x12.6	23.6x11.8x12.6		
Weight	Weight lbs			83.7 105.8		
Clean condition			1			
Working conditions	High steam condition		Enable gas purging	, pressure 0.07MPa;	enable gas ballast	
	Mildly corrosive condition		Enable gas purging, pressure 0.1MPa			

Remark I: See Annex 12.3 for details.
Remark II: When the pump works in the working condition with high water vapor content, run it for a certain period of time after working conditions are met, in order to completely discharge the water vapor in the pump.

Table 3



Some signals of HD8/20/40 inverters have been connected to the connector. See the appearance below

DB15 control terminal corresponding wiring							
Pin No.	I/O	Items		se	Definition of corresponding wire No of inverters	Remark	
1	Rs485+	MODBUS	Communi cation+		SG+	Default communication	
2	Rs485-	MODBUS	Communi cation-		SG-	format 9600-8-N-2	
3							
4	Output	24V			24V		
5	Output	Operation check	Closed: Alarm	Disconnect: Normal	RA	Relay output terminal	
6	Output	Output common			RC	Helay output terminal	
7	Input	Run command	Closed: Running	Disconnect: Shutdown	MI1		
8	Input	Output common terminal 1			DCM		
9	RS485-GND	Communication signal ground			SGND		
10	Input	Speed control	Analog quantity+		AVI	Input analog quantity (0-10V)	
11	Input	Speed control	Analog quantity-		ACM		
12							
13	Input	Analog control startup command			MI2	Analog control terminal	
14							
15	Input	Alarm reset	Closed: Reset		MI6		
Others	Temperature	Motor temperature			MI7		
001613	isinperature	Common			DCM	Common terminal of temperature sensor	


Table 4

Empowering you to work smarter



Control mode

- 1. Local mode: Short connect MI1-DCM for normal operation.
- Communication mode: RS+ is connected with Rs485+, RS- is connected with RS485- and SGND is connected with signal ground.
- 3. Analog quantity mode: Connect MI1-MI2-DCM, connect AVI with analog quantity + and ACM with analog quantity-. Note: Do not run the motor below 3,000 rpm for a long time, for it will seriously damage electrode. For HD20/40, 6.25-10V corresponds to 3,000-4,800 rpm.





Installation Process

6.1 Installation

Confirm the voltage of power supply							
Voltage	foltage 90-120V 200-220V 380-415V						
Models	Wire diameter		Wire diameter		Wire diameter		
HD8	1.5mm²	14AWG	1.5mm²	14AWG			
HD20	1.5mm²	14AWG	1.5mm²	14AWG			
HD40	1.5mm²	14AWG	1.5mm²	14AWG			

- 2. HD20/40 is placed horizontally. A 30cm space is reserved in front and back respectively for heat dissipation.
- 3. Connect the vacuum system to the vacuum pump.
- 4. Connect the exhaust system.
- 5. For HD20/40, it is necessary to connect a dry nitrogen source or a dry compressed air source at the corresponding connection and check that the pressure conforms to the requirements
- 6. For start based on communication, connect the control signal. See Table 6 for details.

HD8/20/40 starts


12


- 7. Turn on the dry nitrogen source or dry compressed air source and adjust the flow to a proper value within the green range indicated by the pressure gauge.
- 8. Turn on the power switch.
- 9. In local mode, plug in the DB15 male connector in the accessory at com1, turn on the switch, and then the vacuum pump will start directly. The upper computer is required to provide operating instructions in communication control mode.
- 10. Check whether the running current is normal

Empowering you to work smarter




6.2 Installation specifications





Overall dimensions of HD series dry screw vacuum pump (unit: inch)									
Model	Α	В	С	D	E	F	Н	1	DN
HD8	20.5	11.8	12.6	13.5	8.2	4.2	11	2.3	KF25
HD20	23.6	11.8	12.6	16.3	8.2	4.2	11	2.3	KF25
HD40	23.6	11.8	12.6	16.3	8.2	4.2	11	2.3	KF25

6.3 Pumping Rate Curve





Handling and Storage



Marning

Do not move the pump until it stops running and power supply has been cut off.



- 1). Any carelessness during handling may cause damage to the pump, so please handle it with care. Move the fully filled pump vertically and horizontally to avoid any oil spillage.
- 2). Please dispose packaging materials as per applicable environmental protection regulations.

Check & Maintenance



14

Warning

- 1). Please check and maintain the product by personnel undergoing corresponding training in strict accordance with safety regulations.
- 2). In case of any hazardous substances, determine their nature first and obey the appropriate safety regulations. If the potential hazard still remains, decontaminate the pump before any maintenance work.

8.1 Daily maintenance list

,	*	
Maintenance Content	Maintenance Cycle	Remark
Oil change interval	After running for 6,000h or oil turns black	8.2.1
Check the pump soun	When running	8.2.2
Change the oil for the first time	After running for 3,000h	8.2.3
Clean the silencer	After running for 6,000h or sound becomes abnormal	8.2.4
Clean the fan cover	Before running	8.2.5
Check wiring	Before running	

Table 5

Empowering you to work smarter



8.2 Routine maintenance methods

8.2.1 Check oil level

- ① When the pump is working, the oil level should always be kept between the lowest and the highest oil level line. Add oil in time, if the liquid level is lower than the lowest line. If the liquid level is higher than the maximum oil level line, unscrew the oil drain plug to drain excess pump oil; otherwise, oil may enter the pump chamber.
- ② Observe the color of pump oil. Normal pump oil is clean and transparent. Change the oil, if it turns dark or becomes turbid.

8.2.2 Check pump sound

① The sound when the pump is running should be continuous and stable and free of any abnormal sound. In case of any abnormal sound, analyze and treat the fault as per Table 7.

8.2.3 Change oil

- ① Change oil after the pump stops and becomes cool, in order to avoid scalding.
- ② To change oil, open the oil drain plug and drain the used oil into a suitable container. When oil stops flowing, screw on the oil drain plug. The oil drain plug and the oil filler plug must be screwed tightly to ensure gearbox airtightness and prevent the entry of any external air, thus causing a lower vacuum degree.
- ③ Drain the replaced oil into a designated container and dispose it in accordance with applicable environmental protection regulations.

8.2.4 Clean the silencer

- ① In case of any abnormal sound when the pump is running or after it stops, check exhaust silencer;
- ② Please stop the pump before checking the exhaust filter. Wait for a period of time until the pump cools
- ③ Open the exhaust port housing at the bottom of the pump, remove the exhaust muffler cover plate, and clean impurities inside the cavity.

8.2.5 Clean fan housing

① Please check whether there is a large amount of dust on the fan housing of the lower fan inlet before running the pump. Ensure full ventilation of fan housing surface in order to avoid affecting heat dissipation and pump performance.




Troubleshooting


9.1 Check Methods for Rotor Rotation

Troubleshooting for rotor sticking

16

- 1. Remove 4 M5x12 stainless steel screws from the front cover plate of the gear, as shown in Fi.6.
- 2. Remove the front cover plate of gear.
 3. Screw off the end face of the front cover of the gear with an 8mm 7-shaped wrench, and align the oil plug of shaft head of the driving and driven rotors, as shown in Fig.7.
- 4. Use a 5mm 7-shaped wrench to turn the driving rotor counterclockwise to experience the resistance during rotation, as shown in Fig.8.






Empowering you to work smarter





Fig.8

- 9.2 Error Code Query of Controller
 Troubleshooting for rotor sticking
 1. Remove 4 M5x12 stainless steel screws from the upper cover plate, as shown in Fig.9.
 2. Remove two M5x12 stainless steel screws in the middle of the left and right-side plates.
- Remove the upper cover plate.
- 4. The location of controller display is shown in Fig.9.





9.3 Examples for Faults

Example: User shall carry out inspection, if pump could not be started normally.

Possible cause 1

Load changes suddenly in working environment and exceeds the bearing range of controller; the controller gives out protective warning (including but not limited to ocX, OvX, and olX).

Solutions for cause 1:

Power off the pump completely for 3 min (unplug and disconnect the switch), reinsert power plug, turn on the switch and access the run command. Then the pump will run normally.

Possible cause 2:

If unplanned shutdown occurs repeatedly in a working environment with high concentration of dust, corrosion and vapor, solid-liquid mixture may attach to the pump gap, which results in the increase of load. Record the controller error code as per the requirements in Fig.9.

Solutions for cause 2:

- 1. Full-cycle start purging (pump shutdown purging and operation purging);
- 2. Use gas ballast in environment with high water vapor.

Possible cause 3:

It's completely stuck.

Solutions for cause 3:

Check whether the rotor is stuck according to the steps shown in Fig.6, Fig.7 and Fig.8.

Example: User shall carry out inspection, if abnormal noise occurs while pump is running.

- Check whether the current of controller is normal according to the requirements in Fig.9;
- 2. Listen carefully to confirm if the motor produces any bnormal noise.

Empowering you to work smarter



Faults	Reasons	Troubleshooting	
	The power supply is not started	1.1 Check power line connection	
	1. The power supply is not started	1.2 Running command is not entered	
	The input power supply voltage is abnormal	Make sure the voltage is within +10% of the rated voltage	
	3. The motor becomes faulty	3. Change motor	
The pump cannot	Enable protection of overload protector	Check ambient temperature or temperature of pumped gas	
be started	5. Ambient temperature is too low	5. Raise ambient temperature by 5°C or above	
	The pump is stuck by foreign matter inside it	6. Repair the pump	
	The pump has been idled for too long a time	7. Repair the pump	
	8. The air outlet is blocked	Clean the exhaust silencer or unblock exhaust pipe	
	The internal parts of the pump are damaged	9. Repair the pump	
	Vacuum system configuration is unreasonable	1. Choose another proper pump	
	2. Leakage of vacuum system	2. Check the system	
	Improper measurement or regulation	Measure the vacuum degree directly at the pump inlet using correct measurement metho and pipe	
The pump can't	4. Air inlet is blocked	4. Clean the air inlet duct	
reach the extreme pressure or	5. Air inlet pipe is too small or too long	5. Use short and thick air inlet pipe	
pumping speed is too slow	6. Air outlet is blocked	6. Unblock air outlet	
	7. Exhaust silencer is blocked	7. Clean the exhaust silencer	
	8. Motor speed is too low	8. Check supply voltage	
	9. Exhaust pipe is blocked	Clean the exhaust silencer or unblock exhaus pipe	
	10. The internal parts of the pump	10. Repair the pump	

20



Faults	Reasons	Troubleshooting		
The vacuum degree of the system drops	Leakage of vacuum system	1. Check the system		
too quickly after the pump stops running	2. No anti-reflux valve	2. Add vacuum valve or anti-reflux valve		
	The input power supply voltage	1.1 Check the connection of power supply, switch and line		
	is abnormal	1.2 Ensure the voltage is within ±10% of the rated voltage		
Abnormal noise during operation	2. Foreign matters inside the pump	2. Repair the pump		
	3. Too low oil level	3. Add oil of specified amount		
	The internal parts of the pump are damaged	4. Disassemble, repair and replace parts		
	Poor installation ventilation	Improve ventilation environment		
	2. The fan is damaged	2. Replace the fan		
	Temperature of the pumped gas is too high	3. Add a cold trap at air inlet		
Pump temperature	4. Exhaust pipe is blocked	4. Clean the exhaust pipe		
rise too high	5. Poor lubrication			
	5.1 Improper or deteriorated pump oil	5.1 Add qualified oil		
	5.2 Insufficient oil in gearbox	5.2 Add oil to specified level		
	5.3 Ambient environment is too high	5.3 Reduce ambient temperature		
Oil exists in the	Oil is from vacuum system	1. Check the vacuum system		
inlet pipeline of the pump	2. Oil level is too high in gearbox	2. Drain off excess pump oil		

Table 6

Empowering you to work smarter



Warranty

We provide 1-year warranty services for the HD series vacuum pump since the date of purchase. During the warranty term, we will provide free maintenance service for any failure occurring on the premise of using the product as per the Manual. We will provide paid services in any of the following conditions:

- (1) Faults caused by natural disasters or human factors.
- (2) Faults caused by special environment.
- (3) Faults caused by abnormal operation or improper use according to our technicians' judgment.
- (4) If the pump is sent back to us for repairing, user needs to state whether the pump is contaminated or contain any substances that do harm to human. If the pump is contaminated, user needs to specify the specific contaminants. We will return the pump to the shipper based on the address, if not receiving any contamination statement.

Accessories

Please use the accessories we supply in order to ensure reliability of the pump. When ordering any accessory, customer needs to provide the pump model and the code of wearing parts. Optional parts are shown in the diagram. For any other requirements for accessories, please feel free to contact us. Accessories we supply:

1. Other types of inlet/exhaust interfaces

2. Dust filter

Way to dispose the product correctly

This mark indicates it is forbidden to dispose the product together with other household wastes. To prevent uncontrolled waste disposal from causing any possible hazards to the environment or human health, please do use a recycling and collection system or contact the retailer where the product was purchased for recycling the product safely and without contaminating the environment.





Annex

12.1 HD8/20/40 MODBUS-RTU Communication Protocol

12.1.1 Communication connection settings

Communication Settings of HD8/20/40							
	MODBUS-RTU: 9600-8-N-2, communication address 1						
Parameter Code	Name	Value					
09-00	Communication address	1~254	1				
09-01	Baud rate	4.8-115.2kbps	9.6				
09-03	Communication timeout	0.0-100.0秒	0				
09-04	COM1 communication format	17, N, 2 (ASCII) 2: 7, E, 1 (ASCII) 2: 7, E, 1 (ASCII) 3: 7, O, 1 (ASCII) 4: 7, E, 2 (ASCII) 5: 7, O, 2 (ASCII) 6: 8, N, 1 (ASCII) 7: 8, N, 2 (ASCII) 8: 8, E, 1 (ASCII) 9: 8, O, 1 (ASCII) 10: 8, E, 2 (ASCII) 11: 8, O, 2 (ASCII) 12: 8, N, 1 (RTU) 13: 6, N, 2 (RTU) 15: 8, O, 1 (RTU) 16: 8, E, 2 (RTU) 17: 8, O, 2 (RTU)	13				
09-09	Communication response and delay time	0.0~200.0ms	2				

Table 7

Empowering you to work smarter



	Specification of HD8/20/40 Inverter			
Items	Specification			
Max. frequency	0~599Hz			
Carrier frequency	2KHz~15KHz			
Input frequency resolution	Digital setting: 0.01Hz			
Control mode	SVC space vector control (open-loop vector control)			
Enabling torque	3Hz/150%			
Steady speed accuracy	±0.5%			
Overload tolerance	At 150% of rated output current, it can withstand 1 minute every 5 minutes; At 200% of rated output current, it can withstand 3 seconds every 30 seconds.			
Frequency setting signal	0-10V			

Table 8



12.1.2 Communication content settings

Communication Contents of HD8/20/40							
Name							
Address	Name	Nature Leng	th Deta	iled Settings of Parameters	Remark		
				00B: No functions			
				01B: Stop	1: After receiving a command, the operation state		
			bit1-0	10B: Start	specified by the command will be		
				11B: JOG starts	maintained until a new command is		
				00B: No functions	received. 2:[Action		
				01B: Forward direction	Command Source] must be set to		
			bit5-4	10B: Reverse direction command	Communication (parameter 00-21 =2) for this field to work.		
				11B: Change current direction command			
				00B: First acceleration and deceleration			
		Read-		01B: Second acceleration and deceleration			
2000H	Running command	write	bit7-6	10B: Third acceleration and deceleration			
				11B: Fourth acceleration and deceleration			
				0000B: Main speed	1: To enable the function of this		
				0001B: First speed	field, bit12 of 2,000h must be set to 1.		
				0010B: Second speed	2: The current running segment		
			0011B: Third speed	speed can be known by reading			
		bit11-8	0100B: Fourth speed	2, 107h.			
			0101B: Fifth speed				
				0110B: Sixth speed			
				0111B: Seventh	1		

Empowering you to work smarter



	Communication Contents of HD8/20/40							
	Name							
Address	Name	Nature	Length	Deta	iled Settings of Parameters	Remark		
					1000B: Eighth speed			
					1001B: Ninth speed			
					1010B: Tenth speed	1: To enable the function of this		
				bit11-8	1011B: Eleventh speed	field, bit12 of 2,000h must be		
2000H	Running command	Read- write		DITTI-8	1100B: Twelfth speed	set to 1. 2: The current running segment speed can be known by reading		
					1101B: Thirteenth speed			
						1110B: Fourteenth speed	2, 107h.	
							1111B: Fifteenth speed	
				bit12	1. Enable bit06-11 functions			
2001H	Frequency command	Read- write	U16	Frequency command (XXX.XX Hz) The standard machine is 2 decimal places; the high-speed machine is 1 decimal place				
2002H	Fault/ Control command source	Read- write	U16	bit0	1: External error (EF) ON	It is used for triggering an external error to the inverter to stop the running state, and the stopping mode can be set by inverter parameters.		
				bit1	1: External error (EF) ON	It is used for clearing error conditions		



		Cor	nmuni	cation Cont	ents of HD8/20/40				
	Control Command								
Address	Name	Nature	Length	Detai	led Settings of Parameters	Remark			
2002H Fault/ Control command source	Fault/Control	Read-		bit2	1: External interrupt (B.B) ON	Triggers an external interrupt to the drive station to suspend operation. When this bit= 0Bl is released, the inverter will immediately resume the original operation state.			
	command source	write	U16	bit5	1: Trigger fire mode	It can prevent the inverter from shutting down due to its own protection, and maintain the important fan operation without following any control signals or alarms			
				State Infor	mation 1				
Address	Name	Nature	Length	Detai	led Settings of Parameters	Remark			
					Running and shutdown state				
					00B: Inverter st (RUN Indicator OFF/STOR				
2101H	Operating state	Read		bit1-0	01B: Inverter is stopping (RUN Indicator flashes/STOP indicator ON)				
2101H	of inverter	nead	U16		10B: Inverter is st (RUN Indicator ON/STOP in				
					11B: Inverter is ru (RUN Indicator ON/STOP				
				bit2	1: Inching comm	and			

Empowering you to work smarter



	Communication Contents of HD8/20/40							
	State Information 1							
Address	Name	Nature	Length	Detai	Detailed Settings of Parameters Remark			
					Direction of open	ation		
					00B: Inverter is in forward (REV indicator OFF/FWD			
				bit4-3	01B: Inverter is currently in r and the target is forwa (REV indicator flashes/FWD	rd rotation		
2101H	Operating state	Read	1116		10B: Inverter is currently in f target is reverse ro (REV indicator ON/FWD ind	otation		
210111	of inverter			016	11B: Inverter is in reverse (REV indicator ON/FWD indicator OFF)			
				bit8	bit8 1: The main frequency source is from the communication interface			
					bit9	The main frequency source analog 1 external term		
						bit10	1: Running command communication int	
				bit11 1: Running command is sent by communication interface				
2102H	Frequency command	Read	U16		Frequency command (XXX.X 1: Speed model speed comr 2: Torque model speed lir	nand		
2103H	Output frequency	Read	U16		Output frequency on inverter (XX	X.XX Hz)		
2104H	Output current	Read	U16	Inverter output current (XX.XXA) when the current is greater than 655.35, automatically become a decimal (XXX.X A). The number of decimal places can be found by referring to the High byte of 211F.				
2105H	DC bus voltage	Read	U16		DC bus voltage of inverter (XX	X.X V)		
2106H	Output voltage	Read	U16	Output voltage of inverter (XXX.X V)				
2107H	Multi-speed state	Read	U16		current segment speed of the m command of the inverter (0 is the			
2109H	Count value	Read	U16		Current count of MI terminal cour	t function		



	Communication Contents of HD8/20/40						
	State Information 1						
Address Name Nature Length Detailed Settings of Parameters Remark							
210AH	Output power factor angle	Read	U16	Inverter output power factor angle (XXX.X) (0.0 ° ~180.0 °)			
210BH	Output torque	Read	U16	Output torque (XXX.X %)			
210CH	Actual motor speed	Read	U16	Actual motor speed (XXX.X rpm)			
210FH	Output power	Read	U16	Output power of inverter (X.XXX kW)			
2116H	Multi-function display	Read	U16	This address is used to display the user-defined LowWord display value for the selected item (parameters 00-04), which is low 16 bits data			
2116H	Multi-function display	Read	U16	When parameter 00-26 is set to 0: this value is equal to the setting of parameter 01-00 When parameter 00-26 is set to non-zero, if the control source is digital Operator: This value = Parameter 00-24x Parameter 00-26 / Parameter 01-00 When parameter 00-26 is set to non-zero, if the control source is 485: This value = Parameter 09-10x Parameter 01-00.			
211FH	Output current	Read	U16	High byte: Current bits (display)			

Empowering you to work smarter



		Cor	nmuni	cation Contents of HD8/20/40				
	State Information 2							
Address	Name	Nature	Length	Detailed Settings of Parameters	Remark			
2200H	Output current	Read	U16	Display the output current of the inverter. When the current is greater than 655.35, it will automatically change to decimal-digit representation (XXX.X A). The number of decimal places can be found by referring to the High byte of 211F.				
2201H	Count value	Read	U16	Count value				
2202H	Output frequency	Read	U16	Actual motor operating frequency	ency			
2203H	DC bus voltage	Read	U16	DC bus voltage (XXX.X V)			
2204H	Output voltage value	Read	U16	U, V and W output voltage value of inverter (XXX.X V)				
2205H	Power factor angle	Read	U16	Power factor angle of inverter output (XXX.X deg)				
2206H	Output power	Read	U16	Display the power of U, V and W output (XXX.X kW)				
2207H	Actual speed of motor	Read	U16	Motor speed estimated by the inverter or fed back by the encoder, in rpm (XXXXX rpm)				
2208H	Output torque	Read	U16	Output positive and negative torque % (+0.0: positive torque;-0.0: negative torque) (XXX.X %)				
220AH	PID feedback value	Read	U16	After the PID function is started, the value is displayed in % (XXX.				
220BH	AVI analog input	Read	U16	Display the signal value of AVI analog inp corresponds to 0.00~ 100.0 (refer to parameter 00-04 desc	00%			
220CH	ACI analog input	Read	U16	Display the signal value of ACI analog 4~20 mA/ 0~ 10 V corresponds to 0.0 (as described in 2)				
220EH	IGBT temperature	Read	U16	Power module IGBT temperature (XXX.X °C)			
2210H	Digital input state	Read	U16	Digital input ON / OFF state, reference parameter 02-12 (reference parameter 00-04 Note 3)				
2211H	Digital output state	Read	U16	Digital input ON / OFF state, reference parameter 02-12 (reference parameter 00-04 Note 4)				



	Communication Contents of HD8/20/40							
	State Information 2							
Address	Address Name Nature Length Detailed Settings of Parameters Remark							
2212H	Multispeed	Read	U16	The segment speed at which the multi- instruction is currently execu				
2213H	CPU pin state corresponding to digital input	Read	U16	CPU pin state corresponding to digital input				
2214H	CPU pin state corresponding to digital output	Read	U16	CPU pin state corresponding to digital output (refer to parameters 00-04 Note 4)				
2216H	Pulse input frequency	Read	U16	Pulse input frequency (XXX.XX Hz)				
2219H	Overload count	Read	U16	Overload count (XXX.XX %)				
221AH	GFF short circuit current to ground	Read	U16	GFF value (XXX.XX %)				
221BH	Bus voltage DC bus chain wave	Read	U16	Bus voltage DC bus chain wave (XXX.X V)				
221CH	PLC register	Read	U16	Value of PLC register D10	43			
221DH	Pole section	Read	U16	Pole section of synchronous m	achine			
221EH	User defined output display	Read	U16	Physical quantity output of u	sers			
221FH	Parameters 00-05 user gain	Read	U16	Output value of parameters 00-05 (XXX.XX Hz)			
2223H	Control mode	Read	U16	Inverter control state 0: Speed mode				
2224H	Carrier frequency	Read	U16	Inverter operating carrier frequency (XX kHz)				

Empowering you to work smarter



Communication Contents of HD8/20/40								
State Information 2								
Address	Name	Nature	Length	Detai	led Settings of Parameters	Remark		
					00b: No directions			
				bit1-0	01b: Forward rotation			
					10b: Reverse rotation			
				bit3-2	01b: Inverter is ready			
2226H	Inverter state	Read	U16	DIT3-2	10b: Error			
			_	bit4	0b: Inverter has no output			
					1b: Inverter has output			
				bit5	0b: No warning			
					1b: YES warning			
2227H	Positive and negative torque	Read	U16	0	utput positive and negative torqui by inverter (XXX Nt-m)	e estimated		
2229H	kWh	Read	U16		kWh display (XXXX.X)			
222EH	PID reference target	Read	U16		PID reference target (XXX.X	X %)		
222FH	PID compensation	Read	U16		PID offset (XXX.XX %)			
2230H	PID output frequency	Read	U16		PID output frequency (XXX.X	X Hz)		
2232H	Auxiliary frequency	Read	U16		Display main frequency			
2233H	Main frequency	Read	U16		Display main frequency			
2234H	Frequency after addition and subtraction of main and auxiliary frequency phases	Read	U16	Display main frequency				

Table 9



12.2 Relationship Between Purge Gas Flow and Purge Pressure of HD20/40 Series

Relationship Between Purge Gas Flow and Purge Pressure of HD20/40 Series							
Flow meter	Flow meter Thermal mass flowmeter TMF-D1002-VO-G1 (Liming from Taiwan)						
Specifications of flow meter	0-100L						
Measuring accuracy	±2.0% of F.S. @25°C						
Installation position	Gas enters the side of exhaust end of the pump body through the relief valve (0-0.35 MPa), barometer (0-0.2 MPa), flowmeter, and one-way valve (starting pressure 0.03 MPa) in order.						
Tubing specification	Total length: 1.5m, pipe outer diameter: @6.35, pipe inner diameter: Φ 4.57						
Purge mode	Pump shutdown purging and operation purging						
Preparations before use	1. Heat up for 30 min; 2. Ventilate and clean the inside of the flowmeter before use.						
Purge mode	HD40						

Relative pressure	Pump shutdown purging (max. range)	Operation purging	Limiting vacuum (The vacuum degree here is for reference only. The measured value of object shall prevail)	Remark
0MPa	/	1	0.56 Pa	According to the actual
0.01MPa	/	/	0.92 Pa	experimental situation: 1. The pressure measured
0.02MPa	/	6-10 L/min	1.09 Pa	when the pump is stopped for purging is relatively
0.03MPa	3-4 L/min	12-16 L/min	1.63 Pa	accurate. 2. While running, flowmeter is still affected by the
0.04MPa	8-12 L/min	16-20 L/min	2.02 Pa	bidirectional pulse air flow, although a flow meter is
0.05MPa	14-18 L/min	22-26 L/min	2.25 Pa	blocked by the one-way valve. Therefore, it is
0.06MPa	26-30 L/min	30-34 L/min	2.61 Pa	required to reserve a sufficient length of pipeline between the pump and the
0.07MPa	38 L/min	34-38 L/min	2.88 Pa	flow meter as far as possible.
0.08MPa	42-46 L/min	44-48 L/min	3.19 Pa	In this Manual, the recommended purge
0.09MPa	52-56 L/min	50-54 L/min	3.62 Pa	pressure is 0.01MPa- 0.09MPa, and the gas flow
0.1MPa	60-64 L/min	56-60 L/min	3.95 Pa	rate is 10-60L/min.

Empowering you to work smarter




Relationship Between Purge Gas Flow and Purge Pressure of HD20/40 Series									
Relative pressure	Pump shutdown purging (max. range)	Operation purging	Limiting vacuum (The vacuum degree here is for reference only. The measured value of object shall prevail)	Remark					
0.11MPa	70-74L/min	60-64 L/min	4.33 Pa	According to the actual					
0.12MPa	72-76 L/min	64-68 L/min	4.7 Pa	experimental situation: 1. The pressure measured					
0.13MPa	82-86 L/min	66-70 L/min	5.1 Pa	when the pump is stopped for purging is relatively					
0.14MPa	88-82 L/min	70-74 L/min	5.63 Pa	accurate. 2. While running, flowmeter is still affected by the					
0.15MPa	92-96 L/min	72-76 L/min	6.11 Pa	bidirectional pulse air flow, although a flow meter is					
0.16MPa	96-100 L/min	76-80 L/min	6.72 Pa	blocked by the one-way valve. Therefore, it is					
0.17MPa	108-112L/min	80-84 L/min	7.13 Pa	required to reserve a sufficient length of pipeline between the pump and the					
0.18MPa	/	/	/	flow meter as far as possible.					
0.19MPa	/	1	/	3. In this Manual, the recommended purge					
0.2MPa	/	1	/	pressure is 0.01MPa- 0.09MPa, and the gas flow					
0.35MPa	/	1	/	rate is 10-60L/min.					

Table 10



12.3 HD8/20/40 Full communication control operation method

12.3.1 Remove the top cover to expose the controller




12.3.2 For inverter operation, you need to adjust the following parameters in the inverter:


Parameters	Instruction	Original	Modified values
PLC	PLC Commands	PLC1	PLC0: PLC function off
00-20	Frequency Command Source Setting	0	1: Communication RS-485 input
00-21	Run Command Source Setting	0	2: Communication RS-485 input


Empowering you to work smarter











12.3.3 Communication parameters

1. Default communication protocol 9600-8-n-2						
2. PLC in	ternal address					
	2000H	Operation Command	16#1: STOP; 16#2: RUNNING			
	2001H	Frequency command	32000: 320Hz			
	Note: SIMATIC S7-200 SMART Add: 2000H=48193					

Empowering you to work smarter	₩ ₩