



Maintenance for ISP-50/90/250/500

Maintenance period and servicing

Years	1	2	3	4	5	6
Hours	8,000	16,000	24,000	32,000	40,000	48,000
Type of maintenance	Minor	Major	Minor	Major	Minor	Replace

The maintenance interval should be based on either the years or the hours, whichever comes first.

Minor Maintenance				
(Every 8,000 hrs)				
	Seals			
Replacement	O-rings			
Treplacement	Exhaust valve			
	Air flush kit			
Other	Cleaning			
Other	Inspect all parts			
	(Re-greasing)			

Major Maintenance				
(Every 16,000 hrs)				
	Same as Minor maintenance			
	+			
Replacement	Tip seals			
	Bearings			
	Spider			
Other	Same as Minor maintenance			